

ITEM	PART NAME
1	Inlet Flange
2	Outlet Flange
3	Button (2)
4	Connecting Rod
5	Body
6	Motor Base
7	Gear Reducer & Cover
8	Crank Arm
11	Rod End Bearing
12	Hardware
	HH1/4-20x7/8 Bolt (8) (inlet/outlet to pump body)
	HN1/4-20 Nut (8) (inlet/outlet to pump body)
	HH1/4-20x1-1/2 Bolt (6) (motor base to pump body)
	HN1/4-20 Nut (6) (motor base to pump body)
	HH3/8-16x1-1/2 Bolt (4) (reducer to motor base)
	HN3/8-16 Nut (4) (reducer to motor base)
	GW3/8 Washer (8) (reducer to motor base)
	HH1/4-20x1-1/2 Bolt (crank arm to reducer)
	GW1/4 Washer (crank arm to reducer)
	HH1/2-13x1-1/2 Bolt (rod end bearing to crank arm)
	HN1/2 x20 Jam Nut (rod end bearing to connecting rod)
	HH1/4-20x2 Bolt (2) (connecting rod to button)
	HN1/4-20 Nut (2) (connecting rod to button)
	O-Ring (2) (button to connecting rod)
	HH1/4-20x1 Bolt (2) (gear reducer cover)
	HN1/4-20 Nut (2) (gear reducer cover)
	HH1/4 Washer (gear reducer cover)
13	Diaphragm
14	Flapper Valves

