

Note:


A part is specified by **Part Model #**.

Part Model # =

Y-Valve Family Model # + "." + Item #

e.g. **YV-094D-B.4** (Handle)

ITEM	PART NAME
1	Body
2	Plug
3	Bonnet
4	Handle
5	Seat
6	Spacer - 0.885 in (3)
7	O Ring #220
8	Machine Screw 10-24 x 1½ (3)
9	Nut 10-24 (3)
10	Machine Screw ¼-20 x ½
11	White Plug
12	Stop Ring
13	Machine Screw #8 x 5/8 PTH
14	Base Mount



Sea-lect® Y-Valve BM-94 Series

Model #: YV-094D-B



930 Waterman Avenue East Providence, RI 02914
Ph: 401-438-1110 888-438-1110 Fax: 401-438-2713
www.thebosworthco.com